


Manual for door/bus telephone Siedle BTC 750-0

Please see details on functions below.



1. Door release; press button for 3 seconds.
2. Door light; used to direct extra light in the direction of the camera.
3. Keys for contrast; + will turn up the contrast, - will turn it down. If there is only a very faint image or no image at all on the monitor, it may be due to contrast is turned way down. Please press + key in a minute or so, or until an image can be seen on the monitor.
4. Keys for color setting; + will turn up the color, - will turn it down
5. Inactive in our installation.
6. Turns off the monitor.
7. Arrow keys are used to point camera in desired direction.